
15 Gallon Diesel Fuel Tank Installation Guide

1. Remove original fuel cap.



2. Remove fuel strainer to access fuel cap chain.



3. Replace chain with new cap chain. Replace strainer into tank. Note: new fuel cap has a pin hole in it for venting.



4. Add anti-slosh valve with some grease/lubricant.

Note: add rubber first and then plastic valve separately with grease in between. Will take some force.



5. Add the fuel shutoff valve to the underside of the tank with fuel grade thread sealant. Note: do not over tighten.



6. Use supplied fuel hose, clamps, and reducer to connect tank to your engine.

